









Sample+RLT (no mix); Beads+IPA (no mix)



Transport to NIMBUS

5x mixes in **2.2 mL plate** (800uL), and no transfer to 1.2 mL plate



5 min binding

Move 2.2mL plate to magnet for 6 min clearing



Wash once with 800uL ALINE wash buffer: no mix



Wash 2 times with 600uL 70% EtOH



Dry 10 min

Elution: 40uL EB, 1 min on magnet with spacer; 25x mixes; incubate 10 min

Step	Sub-Step	Iteration-1	Iteration-2	Remark
Bead-sample mixture	Liquid Class	DfFS	Jet dispense (JetNoBO)	Jet dispense allows higher dispense speed than aspirate speed, which results in better clearing after mixing
	Pause to clear tips after mix	No	Yes (2min)	Allows residual liquid from the surface area for the 1ml tips with 800 μL volume to settle to bottom of the tips
	Clearing time on magnet	6 min	10 min	
	Aspirate supernatant off plate on magnet	Static	Moving aspirate (dllCustAsp)	
Aline Wash Buffer	Conditioning	No	Yes	Prevents percolating which results in hanging droplets
	Pod stays with in wells when wash buffer is removed	No	Yes	
Ethanol Wash	Change tips between washes	No	Yes	
	Pod stays with in wells when wash buffer is removed	No	Yes	
Elution	Mixing	5-point X10=50 times	25 times	
	Aspirate to transfer to destination	Static	Moving	
	Dispense to destination	Static	Moving	
All steps	Slower later pod movement	No	Yes	
	Dispense of waste with trailing air gap	No	Waste	Trailing air gap reduces possible hanging waste droplets
	Disposal of tips	Vibration	waste Chute	No vibration means less possible aerosols



